



caring for your floor

Marmoleum® Click CinchLOC has a strong, durable protective top layer – Topshield™2. This innovation from Forbo ensures a highly effective shield against dirt and scuff marks. Marmoleum® with Topshield™2 is ready for use immediately following installation and does not require the application of additional protective coats of finish. With Topshield™2, your Marmoleum® floor will maintain its beautiful appearance with simple cleaning. Dry dusting is a fast and easy way to keep your floor free from loose dirt. Remove spots with a mop or cloth dampened with diluted Forbo Neutral pH Cleaner. Avoid excessive use of water on the floor, and make sure chair and furniture legs are covered with felt protectors. An entrance mat will protect the floor from dirt.



Initial Care Following Installation

1. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
2. Mix 1/2 – 1 ounce of Forbo Neutral pH Cleaner per 1 gallon of unheated tap water.
3. Apply the solution to the floor. Do NOT flood the floor. The solution can be applied with a mop and bucket.
4. Pick up soil and excess solution with a clean mop. Rinse mops frequently and change the solution as needed.
5. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with a clean, dry mop or towel.
6. Allow the floor to dry thoroughly before allowing traffic.

Routine Floor Care Procedures

1. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
2. Mix 1/2 – 1 ounce of Forbo Neutral pH Cleaner per 1 gallon of unheated tap water.
3. Apply the solution to the floor. Do NOT flood the floor. The solution can be applied with a mop and bucket.
4. For ingrained dirt, a non-abrasive scrubbing sponge may be required.
5. Pick up soil and excess solution with a clean mop. Rinse mops frequently and change the solution as needed.
6. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with a clean, dry mop or towel.
7. Allow the floor to dry thoroughly before allowing traffic.

Spots & Spills

The vast majority of spills can be cleaned off your Marmoleum® satisfactorily. If there are spills or pet “accidents”:

1. Act quickly.
2. Scrape or blot as much as possible.
3. Mop the floor with a solution of Forbo Neutral pH Cleaner.
4. Damp mop with clean water.
5. If necessary, repeat steps 3 and 4. If the stain persists, as it may with glue, varnish, paint, ink, tar, cosmetics, shoe polish, some wines, coffee and some other substances, you may need to allow the solution to sit or “dwell” on the floor for several minutes. Rub the stained area with a green nylon kitchen pad then rinse the area with clean water. Repeat if necessary.

If the stain persists, contact Forbo Product Support & Education Services before trying any other procedures.

For further information on restoration, please contact Forbo’s Product Support & Education Services at +1-800-842-7839.



933858 barbados, 933872 volcanic ash