



### **Storage:**

Protect from frost/freezing.

### **Where to use:**

Interior and exterior bare woodwork

### **Preparation:**

Ensure that woodwork is sound, smooth, dry and free of dust, dirt and grease.

Knots should be treated with ECOS White Knotting Compound.

Fillers should be sealed with ECOS Filler Sealer.

Bare hardwoods - Ask for advice.

**WARNING:** Older buildings may contain lead-based paint, which requires professional remediation if it is disturbed. If in doubt, consult with a professional from a Lead-Safe Certified Firm.

### **Application:**

DO NOT THIN.

Stir gently and thoroughly before use.

Apply one coat to bare wood and allow to dry for at least 6 hours before over-coating.

Normally touch dry in 1-2 hours.

Avoid applying below 41°F (5°C).

Clean equipment and brushes with water.

### **Coverage:**

Varies with porosity:

130 Sq Ft per Quart (single coat)

520 Sq Ft per Gallon (single coat)

### **Health & Safety:**

Avoid contact with skin and eyes. Wash off splashes with water. Keep out of reach of children.