



## PRE-STAIN CONDITIONER

### Storage:

Protect from frost/freezing.

### Where to use:

Properly prepared interior wood substrates such as floors, doors, trim, paneling, cabinets, or furniture.

### Preparation:

Surfaces should be clean, dry, sound and free from dirt, dust, and surface contaminants. Sand substrates first, using either fine sand paper, or a fine sanding pad. DO NOT use steel wool. Always sand in the direction of the natural grain. For hardwood floors, we recommend a lamb's wool applicator. Remove sanding dust with a lightly water-dampened cloth, or tack rag. Always prepare a test sample first on a scrap piece of wood before you begin to ensure a sound technique and to achieve a greater understanding of product performance. Although most stains share some similarities and characteristics, all vary slightly from one to another.

### Application:

Under normal conditions thinning not required. Stir gently before & during use. May be applied using a clean cotton rag, or cloth. If using a brush, maintain a wet edge and do not allow the product to puddle. Remove excess conditioner with a cotton cloth. Use a lamb's wool applicator for floors. Allow 2-4 hours before applying a stain. Finish with a minimum of one coat of stain and two coats of WoodShield Varnish. Avoid applying at temperatures below 50°F (10°C).

### Clean up:

Use warm soapy water.



## PRE-STAIN CONDITIONER

### Coverage:

Maximum spread rate is 100-125 sq ft per quart or 400-500 sq. ft. per gallon depending on substrate porosity.

### Health & Safety:

Avoid overexposure to skin and contact with eyes. Rinse off with water.  
Keep out of reach of children.